# Lafferty Equipment Manufacturing, LLC
# Installation & Operation Instructions

## Model # 974114 · Asphalt Release Airless Foamer

## REQUIREMENTS

**Chemical Concentrate**

**Water**

| | |
|---|---|
| Temperature | up to 160°F |
| Pressure | 35 to 125 PSI |
| Flow | 1.30 GPM @ 40 PSI |
| Supply Line | 1/2" |
| **Hose** | 1/2" ID x 25' |
| **Nozzle** | A-25 Airless Foam Wand |

## OPTIONS

**Stainless Steel Hose Racks**

| | |
|---|---|
| Small Stainless Steel Hose Rack | # 224145 |

**Stainless Steel Jug Racks**

| | |
|---|---|
| 2 ½ Gal. (8 ½" x 10 ½") | # 224210 |
| 5 Gallon (12" x 12") Round/Square | # 224215 |

**Drum & Tote Stick Lengths & Seal Materials**

| | |
|---|---|
| Drum Stick, 33" (Viton or EPDM) | # 491643 / 491643-E |
| Drum Stick, 48" (Viton or EPDM) | # 491648 / 491648-E |
| Drum Stick, 54" (Viton or EPDM) | # 491645 / 491645-E |
| Tote Stick, 33" (Viton or EPDM) | # 491653 / 491653-E |
| Tote Stick, 48" (Viton or EPDM) | # 491654 / 491654-E |
| Tote Stick, 54" (Viton or EPDM) | # 491656 / 491656-E |

**Stainless Steel Airless Foam Wand**

| | |
|---|---|
| Wand, SS, Airless Foam, A-25SS | # 536625SS |

**Alternate Chemical Check Valve - Viton Standard**

| | |
|---|---|
| Check Valve, Chemical, PP(W), 1/4" (EPDM) | # 491401 |

## WEIGHT & DIMENSIONS

**Single Package**

| | |
|---|---|
| Shipping Weight | 10 lbs. |
| Shipping Dimensions | 20" x 18" x 6" |




Lafferty EQUIPMENT MANUFACTURING LLC®

CFS TECHNOLOGIES

www.laffertyequipment.com
501-851-2820

**WARNING!** READ ALL INSTRUCTIONS BEFORE USING EQUIPMENT!

## OVERVIEW

The Asphalt Release Airless Foamer is a 1.3 GPM @ 40 PSI airless foam applicator for applying asphalt release chemicals on to truck beds or tools to prevent asphalt from sticking. This venturi injection system uses standard city water pressure (35 - 125 PSI) and precision metering tips to draw and blend chemical concentrate into the water stream to create an accurately diluted solution. The solution is then projected through the discharge hose and wand to the "airless" foam wand which draws in atmospheric air to create and project wet, clinging foam.

## SAFETY & OPERATIONAL PRECAUTIONS

- **When connecting to a potable water supply follow all local codes for backflow prevention.**
- **WARNING: Severe damage to your facility, or contamination of your potable water supply, can occur without proper backflow prevention.**
- For proper performance do NOT modify, substitute nozzle, hose diameter or length.
- Manufacturer assumes no liability for the use or misuse of this unit.
- Wear protective clothing, gloves and safety goggles when working with chemicals.
- Always direct the discharge away from people and electrical devices.
- For pressures over 100 PSI, remove the discharge valve or lower pressure.
- Never leave inlet ball valves on when unit is not in use.
- Follow the chemical manufacturer's safe handling instructions.
- NEVER mix chemicals without first consulting chemical manufacturer.

## TO INSTALL (REFER TO DIAGRAM ON NEXT PAGE)

**If you are connecting to a potable water supply follow all local codes for backflow prevention.**

1. Mount the unit to a suitable surface above the chemical supply to prevent siphoning.
2. Connect hose(s) as shown in the diagram.
3. Flush any new plumbing of debris before connecting water.
4. Connect water supply. Install a water filter if water piping is older or has known contaminants.

**Set the chemical dilution ratio by threading one of the color coded metering tips into each chemical check valve. See chemical labels for dilution ratio recommendation or consult your chemical supplier.**

- For the strongest dilution ratio do NOT install a colored metering tip.
- The dilution ratios in the metering tip chart are based on water thin chemicals with a viscosity of 1CPS.
- Thicker chemicals will require a larger tip than the ratios shown in the chart.
- Application results will ultimately determine final tip color.
- Select the tip color that is closest to your desired chemical strength and thread it into the tip holder. **DO NOT OVER-TIGHTEN.**
- Push the chemical tube over the check valve barb and place the suction tube in the chemical concentrate.
- If necessary, cut suction tube(s) to length before attaching suction strainer.

## TO OPERATE

**Always make sure the discharge ball valve is closed or pointed in a safe direction before turning water on. Ball valve can be shut off at any time during operation but should not be left unattended for long periods of time.**

1. Open the inlet ball valve then open the discharge ball valve to begin application.
2. Make final metering tip adjustments based on application results.
3. When application is completed, close the discharge ball valve, return to the unit and close the inlet ball valve. Re-open the discharge ball valve to relieve pressure in hose then close the discharge ball valve. If applicable rinse the work surface before solution dries.

### METERING TIP SELECTION

| METERING TIP COLOR | OZ/MIN | DILUTION RATIO @ 40 PSI |
|---|---|---|
| Brown | 0.56 | 297:1 |
| Clear | 0.88 | 189:1 |
| Bright Purple | 1.38 | 121:1 |
| White | 2.15 | 77:1 |
| Pink | 2.93 | 57:1 |
| Corn Yellow | 3.84 | 43:1 |
| Dark Green | 4.88 | 34:1 |
| Orange | 5.77 | 29:1 |
| Gray | 6.01 | 28:1 |
| Light Green | 7.01 | 24:1 |
| Med. Green | 8.06 | 21:1 |
| Clear Pink | 9.43 | 18:1 |
| Yellow Green | 11.50 | 14:1 |
| Burgundy | 11.93 | 14:1 |
| Pale Pink | 13.87 | 12:1 |
| Light Blue | 15.14 | 11:1 |
| Dark Purple | 17.88 | 9:1 |
| Navy Blue | 25.36 | 7:1 |
| Clear Aqua | 28.60 | 6:1 |
| Black | 50.00 | — |
| No Tip Ratio Up To: | | 5:1 |

The dilution ratios above are approximate values. Due to chemical viscosity, actual dilution ratios may vary.


### FORMULA

**GPM × 128 ÷ Desired Dilution Ratio = oz/min**

- *See Unit Flow Rates chart for GPM*
- *Use 20 for 20:1 dilution ratio, 30 for 30:1, etc.*
- *Match calculated ounces per minute (oz/min) to nearest oz/min in Metering Tip Selection chart.*

### UNIT FLOW RATES

| PSI | GPM |
|---|---|
| 35 | 1.22 |
| 40 | 1.30 |
| 50 | 1.45 |
| 60 | 1.59 |
| 70 | 1.72 |
| 80 | 1.84 |
| 90 | 1.95 |
| 100 | 2.06 |
| 110 | 2.16 |
| 120 | 2.25 |
| 125 | 2.30 |


Backflow Preventer
(Not Included)
Water Inlet
GH Washer
With Screen
#102050
GH Adapter,
3/4" Garden Hose
#102023
Ball Valve
#413612
Uni-Body W-25HC
Injector Body
#391025HC
Elbow
#257378SS
Lafferty
ASPHALT RELEASE
AIRLESS FOAMER
Check Valve
(PP/Viton)
#491402
Metering Tips
Color-Coded 20-Pack
#443798
Hose Barb
1/2" x 1/2" MPT
#119272SS
Hose Clamp
#134302
Suction Tube, 6'
#473007
Suction Strainer
#150115
To Chemical
A-25 Airless Foam Wand
#536625
Wand
#536518
Ball Valve
#413620RH
Hose, 1/2" x 25'
#803425

# Troubleshooting Guide

| Problem | Possible Cause / Solution | |
|---|---|---|
| | Startup | Maintenance |
| A) Will not draw chemical | 1, 5, 6, 7, 8, 10 | 11, 12, 13, 14, 15, 16, 17 |
| B) Foam does not clean or foam properly | 2, 4, 5, 7, 8, 9 | 10, 11, 12, 13, 14, 15, 16 |
| C) Using too much chemical | 3 | |
| D) Water backing up into chemical container | 10 | |

## Possible Cause / Solution

### Startup

1. **Inlet ball valve not completely open**
   - Completely open the inlet ball valve.
2. **Not enough chemical - metering tip too small**
   - Install larger metering tip.
3. **No metering tip installed or metering tip too large**
   - Install smaller metering tip.
4. **Improper chemical**
   - Ensure product is recommended for foaming and the application.
5. **Chemical tube not immersed in chemical or chemical depleted**
   - Immerse tube or replenish.
6. **Discharge hose too long or wrong size or kinked**
   - Straighten the hose or replace hose with correct size.
7. **Discharge ball valve not completely open**
   - Completely open the discharge ball valve.
8. **Water pressure or water volume too low/inlet piping too small causing poor chemical pick up**
   - Increase water pressure or water volume
9. **Soil has hardened on surface; always rinse before chemical dries**
   - Reapplication may be necessary.

### Maintenance

10. **Chemical check valve stuck or failed**
    - Clean or replace.
11. **Chemical strainer or metering tip partially blocked**
    - Clean or replace chemical strainer and/or metering tip.
12. **Chemical tube stretched out or pin hole/cut in chemical tube**
    - Cut off end of tube or replace tube.
13. **Vacuum leak in chemical pick-up connections**
    - Tighten the connection.
14. **Water strainer clogged or missing/injector inlet orifice clogged**
    - Clean or replace strainer; check/clean inlet orifice for obstructions. DO NOT DRILL OUT.
15. **Hard water scale or chemical build-up may have formed in the injector body causing poor or no chemical pick-up**
    - Follow Preventive Maintenance instructions below, using hot water and/or de-scaling acid. When there is no draw at all, carefully remove fittings and soak entire injector body in de-scaling acid.
16. **Foam wand clogged or scaled up / wrong nozzle**
    - Hard water scale or chemical build-up may have formed, soak entire foam wand in de-scaling acid / see requirements.
17. **More than one chemical ball valve open or no chemical valve open**
    - 2 & 3 Way models only

PREVENTIVE MAINTENANCE: When the unit will be out of service for extended periods, place chemical tube(s) in water and flush the chemical out of the unit to help prevent chemical from drying out and causing build-up. Periodically check and clean chemical strainer and replace if missing.