# Lafferty Equipment Manufacturing, LLC Installation & Operation Instructions

## Model # 985200SS · 2-Way Ball Valve SS Mixing Station

REQUIREMENTS  Chemical Concentrate			
Temperature	up to 160°F		
Pressure	25-125 PSI		
Supply Line	1/2" Minimum		
Flow			
High Flow	4.0 GPM @ 40 PSI		
Low Flow	1.95 GPM @ 40 PSI		

OPTIONS	
Stainless Steel Jug Racks	
1 Gallon Round/Square	# 224200
1 Gallon Round/Square Locking	# 224200-L
2 ½ Gallon (8 ½" x 10 ½")	# 224210
5 Gallon Round/Square Locking (12" x 12")	# 224214
5 Gallon Round/Square (12" x 12")	# 224215
Safe Flow Lid™ for 1 Gallon Jugs Lid, Suction Tube, and Strainer	# 709101
Alternate Check Valve - Kalrez Standard Check Valve, Chemical, SS, EPDM, 1/4"	# 491324
Check Valve, Chemical, SS, Viton, 1/4"	# 491324-V
Jumper Hose with GH Fittings (10') GH Hose, Blue, 1/2" x 10'	# 804410B
Red, Blue, Green & Yellow Ball Valve Handles	

# 413511RED, 413511BLU, 413511GRN, 413511YLW





www.laffertyequipment.com 501-851-2820

WARNING! READ ALL INSTRUCTIONS BEFORE USING EQUIPMENT!





### **OVERVIEW**

The 2-Way Ball Valve SS Mixing Station is a solvent-resistant, ASSE 1055 certified chemical proportioner that accurately dilutes chemicals to the required ratios and dispenses into any size container. This stainless steel venturi injection system uses city water pressure (25 - 125 PSI) to draw and blend chemical concentrate into the water stream and precision metering tips to set the dilution ratio for each valve. Ball valve activation allows for hands-free dispensing. Choose a factory-set flow rate for each ball valve at the time of order (Low Flow or High Flow).

### **SAFETY & OPERATIONAL PRECAUTIONS**

- For proper performance do NOT modify hose diameter or length.
- Do NOT attempt to install a discharge ball valve.
- Manufacturer assumes no liability for the use or misuse of this unit.
- When connecting to a potable water supply follow all local codes for backflow prevention.
- WARNING: Contamination of your potable water supply can occur without proper backflow prevention.
- Wear protective clothing, gloves and eye wear when working with chemicals.
- Always direct the discharge away from people and electrical devices.
- Follow the chemical manufacturer's safe handling instructions.
- · Never use chemicals that could be dangerous if accidentally mixed.

#### Installation for Devices Plumbed to a Faucet with a Vacuum Breaker

- This equipment features an integrated hose connection vacuum breaker.
- In cases where an installation involves a water source coming from a faucet with an integrated vacuum breaker device conforming to ASSE 1001 or ASSE 1011, a pressure bleed device conforming to IAPMO PS-104 shall be used to protect the vacuum breaker device.
- The purpose is so that continuous pressure does not adversely affect the vacuum breaker device upstream of the
  pressure bleed device. This also protects against a cross-connection between hot and cold water migration by
  encouraging the user to turn off the water supply at the faucet.

Device certified to meet ASSE Standard 1055 (Chemical Dispensing Systems with Integral Backflow Prevention)



### TO INSTALL (REFER TO DIAGRAM ON NEXT PAGE)

- 1. Attach discharge tubes (see diagram). Discharge tubes can be cut to length as needed.
- NOTE: Do not install a shutoff or flow restriction device on end of discharge hose (valve, trigger, nozzle, etc.)
   This unit is designed for open flow dispensing.
- Mount to suitable surface <u>above the chemical</u> to prevent siphoning. Use suitable fasteners based on the mounting surface and system weight. See diagram for mounting hole size and spacing.
- 3. Select and install metering tips and suction tubes by following instructions below TO SET DILUTION RATIO.
- 4. To prevent blocking the small orifices inside the injector, flush debris from new plumbing before connecting. If water piping is older and has known contaminants, install a water filter. Always use the included washer with screen on the unit inlet.
- 5. Connect water supply.
- 6. Immerse chemical suction tubes with strainers into container(s) of chemical concentrate.

# TO SET DILUTION RATIO, thread a color-coded metering tip into each tip holder. See chemical labels for dilution ratio recommendation or consult your chemical supplier.

- For the strongest dilution ratio do NOT install a colored metering tip.
- The dilution ratios in the metering tip chart are based on <u>water thin</u> chemicals with a viscosity of 1CPS. <u>Thicker</u> chemicals will require a larger tip than the ratios shown in the chart.
- Chart shows ratios at 40 PSI water pressure. Actual water pressure is shown on unit gauge during operation.
   Adjust metering tip selection based on actual water pressure using the online <u>Metering Tip Calculator</u> or the math formula shown in the chart.
- Select and thread the tip color that is closest to your desired chemical strength into the tip holder. DO NOT OVER-TIGHTEN
- Application results will ultimately determine final tip color selection.
- Push the chemical tubes over the tip holders and place the strainer in the chemical concentrate.
- If necessary, cut suction tube(s) to length.

If a leaner solution than the maximum shown in the chart is required, it will be necessary to use one proportioner to predilute the concentrate, and a second to dilute the resulting solution to the required final ratio. If this <u>Double Dilution</u> procedure is required, choose two metering tips whose ratios, when multiplied together, result in a ratio that is as close as possible to the required final ratio. *Example: For two "Bottle Fill" Mixing Station valves with 40 PSI water pressure, use a White Tip (37:1) and a Corn Yellow Tip (21:1) to achieve a final solution ratio of 777:1.* 

### **TO OPERATE**

- 1. Place the discharge hose in the container then open the appropriate inlet ball valve.
- When container is filled to the desired level close the inlet ball valve leave the hose in the container a few extra seconds to drain the hose.
- 3. Repeat step 1 & 2 for additional chemicals.
- Make final metering tip adjustments based on application results. Try the next larger or smaller sized metering tip until the results are acceptable.

METERING TIP SELECTION				
METERING TIP COLOR	OZ/MIN	DILUTION RATIO @ 40 PSI		
		HIGH FLOW	LOW FLOW	
Brown	0.56	914:1	446:1	
Clear	0.88	582:1	284:1	
Bright Purple	1.38	371:1	181:1	
White	2.15	238:1	116:1	
Pink	2.93	175:1	85:1	
Corn Yellow	3.84	133:1	65:1	
Dark Green	4.88	105:1	51:1	
Orange	5.77	89:1	43:1	
Gray	6.01	85:1	42:1	
Light Green	7.01	73:1	36:1	
Med. Green	8.06	64:1	31:1	
Clear Pink	9.43	54:1	26:1	
Yellow Green	11.50	45:1	22:1	
Burgundy	11.93	43:1	21:1	
Pale Pink	13.87	37:1	18:1	
Light Blue	15.14	34:1	16:1	
Dark Purple	17.88	29:1	14:1	
Navy Blue	25.36	20:1	10:1	
Clear Aqua	28.60	18:1	9:1	
Black	50.00	10:1	5:1	
No Tip Ratio Up To:		9:1	4:1	


The dilution ratios above are approximate values. Due to chemical viscosity, actual dilution ratios may vary.

#### **FORMULA**

### GPM × 128 ÷ Desired Dilution Ratio = oz/min

- · See Unit Flow Rates chart for GPM
- Use 20 for 20:1 dilution ratio, 30 for 30:1, etc.
- Match calculated ounces per minute (oz/min) to nearest oz/min in Metering Tip Selection chart.

UNIT FLOW RATES		
PSI	GF	PM
P31	HIGH FLOW	LOW FLOW
35	3.74	1.82
40	4.00	1.95
50	4.47	2.18
60	4.90	2.39
70	5.29	2.58
80	5.66	2.76
90	6.00	2.93
100	6.32	3.08
110	6.63	3.23
120	6.93	3.38
125	7.07	3.45



- Page 3 -

# **Troubleshooting Guide**

Problem	Possible Cause / Solution		
	Startup	Maintenance	
A) Unit will not draw chemical.	1, 2, 3	6, 7, 8, 9, 10, 11	
B) Dilution too weak.	4	11	
C) Dilution too strong	5		
D) Water backing up into chemical container.		8	
E) Vacuum breaker constantly dripping / leaking.		12, 13	

Startup	Maintenance	
Water pressure too low or water temperature too high	6. Water inlet strainer screen clogged  • Disconnect water and clean the screen.	
<ul><li>2. Ball valve not completely open</li><li>Completely open the ball valve.</li></ul>	7. Chemical strainer or metering tip partially blocked  • Clean or replace chemical strainer and/or metering tip	
<ul> <li>Chemical tube not immersed in chemical or chemical depleted</li> <li>Immerse tube or replenish.</li> </ul>	<ul> <li>8. Check valve stuck or failed <ul> <li>Clean or replace.</li> </ul> </li> <li>9. Vacuum leak in chemical pick-up connections</li> </ul>	
<ul><li>4. Metering tip too small</li><li>Install larger metering tip.</li></ul>	Tighten the connection.  10. Chemical tube stretched out where tube slides over	
5. No metering tip installed or metering tip too large  • Install smaller metering tip.	metering tip holder or pin hole/cut in chemical tube (sucking air in)  • Cut off end of tube or replace tube.	
	11. Water scale or chemical build-up may have formed in the body causing poor or no chemical pick-up  • Follow Preventive Maintenance instructions below, using hot water and/or descaling acid. When there is draw at all, carefully remove fittings and soak entire body in descaling acid.	
	<ul><li>12. Vacuum breaker fouled or failed</li><li>Replace vacuum breaker.</li><li>Install filter on water supply line.</li></ul>	
	Vacuum breaker experiencing backpressure     The vacuum breaker(s) will vent water when experiencing backpressure that cannot exist under normal operating conditions.     Do not exceed maximum water pressure. See requirements.     Do not modify discharge assembly, attach shutoff valvor otherwise restrict flow from unit discharge.     Descale injector body, if necessary.	

PREVENTIVE MAINTENANCE: When the unit will be out of service for extended periods, place chemical tube(s) in water and flush the chemical out of the unit to help prevent chemical from drying out and causing build-up. Periodically check and clean chemical strainer and replace if missing.

