# Lafferty Equipment Manufacturing, LLC Installation & Operation Instructions

### Model # 917907 · 2-Way A-20SS Airless Foamer

# REQUIREMENTS Chemical Concentrate Water Up to 180°F Pressure 400 to 1000 PSI Flow 3.1 GPM @ 700 PSI Supply Line 3/8" Hose 3/8" ID x 50' Nozzle A-20 Airless Foam Wand

OPTIONS	
Stainless Steel Hose Racks	
Large Stainless Steel Hose Rack	# 224150
Stainless Steel Jug Racks	
Jug Rack, SS, 1 Gallon, Round/Square	# 224200
Jug Rack, SS, 2 1/2 Gallon	# 224210
Jug Rack, SS, 5 Gallon, Round/Square	# 224215
Safe Flow Lid™ for 1 Gallon Jugs	
Lid, Suction Tube, and Strainer	# 709101
Alternate Check Valve - EPDM Standard	
Check Valve, Chemical, PP/Viton, 1/4"	# 491315





www.laffertyequipment.com 501-851-2820



### **OVERVIEW**

The 2-Way A-20SS Airless Foamer is a 3.1 GPM @ 700 PSI foam applicator for projecting up to 2 foaming chemicals on to any surface up close or at a distance without compressed air. This stainless steel venturi injection system uses high water pressure (400 - 1000 PSI) to draw and blend chemical concentrates into the water stream to create accurately diluted solutions. The solutions then flow through the foam hose and trigger gun to the "airless" foam wand which draws in atmospheric air to create and project wet, clinging foam at distances up to 12 feet. Use the ball valves to inject the 2 chemicals separately or simultaneously.

### **SAFETY & OPERATIONAL PRECAUTIONS**

- For proper performance do NOT modify, substitute nozzle, hose diameter or length.
- Manufacturer assumes no liability for the use or misuse of this unit.
- Wear protective clothing, gloves and eye wear when working with chemicals.
- Always direct the discharge away from people and electrical devices.
- Follow the chemical manufacturer's safe handling instructions.

### TO INSTALL (REFER TO DIAGRAM ON NEXT PAGE)

If you are connecting to a potable water supply follow all local codes for backflow prevention.

- 1. Mount the unit to a suitable surface above the chemical supply to prevent siphoning.
- 2. Connect hose(s) as shown in the diagram.
- 3. Flush any new plumbing of debris before connecting water.
- 4. Connect water supply. Install a water filter if water piping is older or has known contaminants.

Set the chemical dilution ratio by threading one of the color coded metering tips into each chemical check valve. See chemical labels for dilution ratio recommendation or consult your chemical supplier.

- For the strongest dilution ratio do NOT install a colored metering tip.
- The dilution ratios in the metering tip chart are based on water thin chemicals with a viscosity of 1CPS.
- Thicker chemicals will require a larger tip than the ratios shown in the chart.
- · Application results will ultimately determine final tip color.
- Select the tip color that is closest to your desired chemical strength and thread it into the tip holder. DO NOT OVER-TIGHTEN.
- Push the chemical tube over the check valve barb and place the suction tube in the chemical concentrate.
- If necessary, cut suction tube(s) to length before attaching suction strainer.

### **TO FOAM**

- 1. A fan nozzle for fast coverage or a zero degree nozzle for distance are included.
- 2. Select and install the nozzle you want to use in the foam wand.
- 3. Make final metering tip adjustments based on foam quality and cleaning results.
- 4. With trigger gun in hand open the inlet ball valve and 1 chemical ball valve.
- 5. Pull the trigger and begin application.
- 6. When application is completed, release the trigger then close the inlet ball valve and the chemical ball valve.
- 7. Briefly squeeze the trigger to relieve pressure in hose.

METERING TIP SELECTION					
METERING TIP COLOR	OZ/MIN	DILUTION RATIO @ 700 PSI			
Brown	0.56	711:1			
Clear	0.88	452:1			
Bright Purple	1.38	288:1			
White	2.15	185:1			
Pink	2.93	136:1			
Corn Yellow	3.84	104:1			
Dark Green	4.88	82:1			
Orange	5.77	69:1			
Gray	6.01	66:1			
Light Green	7.01	57:1			
Med. Green	8.06	49:1			
Clear Pink	9.43	42:1			
Yellow Green	11.50	35:1			
Burgundy	11.93	33:1			
Pale Pink	13.87	29:1			
Light Blue	15.14	26:1			
Dark Purple	17.88	22:1			
Navy Blue	25.36	16:1			
Clear Aqua	28.60	14:1			
Black	50.00	8:1			
No Tip Ratio Up To:		7:1			
The dilution ratios above are approximate values. Due to					


The dilution ratios above are approximate values. Due to chemical viscosity, actual dilution ratios may vary.

### **FORMULA**

### GPM × 128 ÷ Desired Dilution Ratio = oz/min

- See Unit Flow Rates chart for GPM
- Use 20 for 20:1 dilution ratio, 30 for 30:1, etc.
- Match calculated ounces per minute (oz/min) to nearest oz/min in Metering Tip Selection chart.

UNIT FLOW RATES			
PSI	GPM		
400	2.35		
500	2.63		
600	2.88		
700	3.11		
800	3.32		
900	3.53		
1000	3.72		



## **Troubleshooting Guide**

Problem	Possible Cause / Solution		
	Startup	Maintenance	
A) Unit will not draw chemical	1, 5, 6, 7	10, 11, 12, 13, 14	
B) Foam does not clean or foam properly	2, 4, 5, 7, 8	10, 11, 12, 13, 14	
C) Using too much chemical	3		
D) Water backing up into chemical container		9	

	Possible Cau	use / Solution
	Startup	Maintenance
1.	Inlet ball valve not completely open	9. Chemical check valve stuck or failed
	<ul> <li>Completely open the ball valve.</li> </ul>	<ul> <li>Clean/disassemble and turn seat over or order reb kit.</li> </ul>
2.	Not enough chemical - metering tip too small	MG
	<ul> <li>Install larger metering tip.</li> </ul>	10. Chemical strainer or metering tip partially blocked  ○ Clean or replace chemical strainer and/or metering
3.	No metering tip installed or metering tip too large	- Olean of replace themical strainer and/or metering
	<ul> <li>Install smaller metering tip.</li> </ul>	11. Chemical tube stretched out or pin hole/cut in chemic tube (sucking air in)
4. Improper chemical	• Cut off end of tube or replace tube.	
	<ul> <li>Ensure product is recommended for foaming and the</li> </ul>	out on the or tabe or replace tabe.
	application.	12. Vacuum leak in chemical pick-up connections
5.	Chemical tube not immersed in chemical or chemical	∘ Tighten the connection.
	depleted	13. Water strainer clogged or missing/injector inlet orifice
	<ul> <li>Immerse tube or replenish.</li> </ul>	clogged
6.	Discharge hose too long or wrong size (SEE	Clean or replace strainer; check/clean inlet orifice obstructions. DO NOT DRILL OUT.
R	REQUIREMENTS)	Obstructions. Bo Not British 601.
	Replace hose with correct size/length.	14. Hard water scale or chemical build-up may have formed the injector body or foam wand causing poor or no
<ul> <li>7. Water pressure or water volume too low/inlet piping too small causing poor chemical pick up         <ul> <li>Increase water pressure or water volume (SEE REQUIREMENTS).</li> </ul> </li> </ul>	Water pressure or water volume too low/inlet piping too	chemical pick-up
	small causing poor chemical pick up	Follow Preventive Maintenance instructions below.
	using hot water and/or de-scaling acid. When there draw at all, carefully remove fittings and soak entire	
8.	Soil has hardened on surface; always rinse before it dries  • Reapplication may be necessary.	injector body and/or foam wand in de-scaling a

PREVENTIVE MAINTENANCE: When the unit will be out of service for extended periods, place chemical tube(s) in water and flush the chemical out of the unit to help prevent chemical from drying out and causing build-up. Periodically check and clean chemical strainer and replace if missing.

